



Concept

WIRE INDUSTRIES

www.conceptwire.com.au

How to put a coil of baling wire on to a stem

First, slide the stem through the centre of the coil, making sure the yellow arrow is pointing to the top. In this photo, the yellow arrow is pointing away from the worker.



Second, position the forklift to the side of the coil, and push **ONLY ONE** fork tine through the end of the stem.



Now begin to lift the fork tines up. The stem will slide as the forks go up. As the stem lifts off the ground, it may swing a little from side to side, but because you have positioned the fork lift on the side, the stem will NOT slide off the fork tines.



The stem is now vertical and ready to be moved around as required.

